

# Indicators

## T71P

### Multifunctional 7000 Series ABS Indicator For Advanced Applications

- Advanced applications including accumulation, library and optional alibi memory
- The 7000 Series Indicators have enough power to drive up to 8 - 350 ohm load cells and a dual scale mode allowing one indicator to display the weights from two bench scale bases or floor scale platforms
- User configurable resolution up to 50,000d plus multiple interface and relay options

**Application** Weighing, Display Hold, Dynamic Weighing, Counting, Checkweighing, Percent Weighing, Accumulation, Library of up to 256 records

**Display** LCD display with white LED backlight, alphanumeric line and multi-language, plus 3 color checkweigh LED

**Operation** Internal Universal Power Supply (Included), 6 x C (LR14) Batteries (Not Included) or Optional Internal NiMH Rechargeable Battery

**Communication** RS232 Interface with GMP, Time-Date, second base input and external tare switch input included, optional RS422/485, AC/DC Relay, 2nd RS232

**Construction** ABS housing and painted steel mounting bracket

**Design Features** Alpha numeric keypad, reversible rear cover for cable exit above or below the indicator housing, non-slip rubber feet, simple plug-and-play installation of options, 50,000d and up to 10,000e



Model	Item No.	Price USD
T71P	83998180	495

## T51XW

### Multifunctional 5000 Series Washdown Indicator

- NEMA 4X/ IP66 stainless steel housing
- Multiple interface and relay options
- High resolution, user configurable up to 30,000d

**Application** Weighing, Display Hold, Dynamic Weighing, Parts Counting, Checkweighing, Percent Weighing

**Display** LCD display with white LED backlight plus 3 color checkweigh LED

**Operation** Internal Universal Power Supply or Optional Internal NiMH Rechargeable Battery

**Communication** RS232 Interface with GMP with Time-Date, external tare switch input included, optional RS422/485, AC/DC Relay, 2nd RS232

**Construction** NEMA 4X/IP66 stainless steel housing and mounting bracket

**Design Features** Hinged front cover for easy servicing, simple plug-and-play installation of options, 30,000d and up to 10,000e



Model	Protection Rating	Item No.	Price USD
T51XW	IP66; NEMA 4X	83999840	549